# INSTRUCTION SHEET **POVIERTEC. Complete Doweling Jig Kit QUESTION...** 1.847.780.6120

**NOTE:** These doweling jigs can be used with any size stock, but each individual jig is designed for a specific size stock.

71497: 3/8" doweling jig to center dowels in 3/4" stock

71496: 1/4" doweling jig to center dowels in 1/2" stock

71498: 1/2" doweling jig to center dowels in 1" stock.


**NOTE:** Failure to follow these instructions could result in misalignment

## PACKAGING CONTENTS

- 1 71497: 3/8" doweling jig (contains jig, cobalt 3/8" drill bit, stop collar and hex wrench)
- 1 71496:1/4" doweling jig (contains jig, cobalt 1/4" drill bit, stop collar and hex wrench)
- 1 71498: 1/2" doweling jig (contains jig, cobalt1/2" drill bit, stop collar and hex wrench)

## TO USE


 Use a square to draw a straight line where the two pieces will be joined. See Figure1.



## MODEL NO. 71397


- 2. Place the body of the jig flat on the workpiece
- 3. With the body flat on the workpiece, set the hairline cursor in the center of the pencil mark. See Figure 2.

### Figure 2




- Clamp the jig to the workpiece. MAKE SURE the hairline cursor and pencil mark are still aligned.
- 5. Determine the depth of the hole to be drilled based on the length of the dowel being used.
- 6. Set the stop collar and tighten the clamp screw. See Figure 3.

#### Figure 3




7. Drill the hole. MAKE SURE the set up and drill are as straight as possible. See Figure 4.



8. Glue and assemble the pieces as per the dowel instructions.

**NOTE:** If after following the *To Use* instructions the marks are not properly aligning, use a square to verify the hairline is perpendicular to the body. If the hairline is NOT perpendicular, loosen the two screws, reset the hairline and re-tighten. See Figure 5.

#### Figure 5



Visit us on the web at powertecproducts.com



Put these instructions and the original sales invoice in a safe, dry place for future reference.