

1. Depress the lock lever on the base of the pipe clamps and slide a 3/4" pipe through the holes in the clamps. Releasing the lock lever will lock the pipe in place.
2. Depress the lock levers again and move the clamps in and out on the pipe to fit the object being clamped. Move the clamps until the clamp faces are against the object being clamped. **NOTE:** If needed, make sure the pivot handle is horizontal so it clears the pipe.
3. Thread the pivot handle in to secure the object. When the object is secure flip the pivot handle into the right angle position.

NOTE: The pipe clamps can be reversed with the clamp faces in opposite directions to be used as a spreader.

